

# 100% Solids Epoxy Floor Coating



**1. Abrade Floor**



**2. Scrape and Remove Loose Areas**



**3. Prime Floor**



**4. Fill / Repair Prepped Areas**



**5. Smooth Repaired Areas**



**6. Apply 100% Solids Epoxy Coating**



**7. Broadcast Aggregate**



**8. Finished Product 1**



**9. Ready To Be Enjoyed!**